

Part B. Adding Neck Draw & Binding - continued

2. **Attaching binding** to top of piece - continued

(b.) Fold binding fabric **over in half** to the lining side & sew in place on *lining side* - sew approximately 1/8" to 1/4" from the **inside** edge of the binding.

(c.) Trim sides of the binding.



Part C. Finishing

1. Fold right sides of bag piece together (bag is now inside-out) and sew the **sides** together using 1/2" seam allowance.

When sewing make sure neck draw "ends" (now inside of the bag) are loose and not accidentally in the seam allowance. Check this when sewing.

2. Next, sew **bottom** of bag piece right sides together using 1/2" seam allowance.

